



- 1 ON/OFF BLOWER
  - 1<sup>st</sup> Press: The blower starts
  - 2<sup>nd</sup> Press: The blower stops
- 2 BLOWER SPEED VARIATION +
  - Press & hold to increase the blower speed
  - Release pressure at the desired speed
- 3 BLOWER SPEED VARIATION -
  - Press & hold to decrease the blower speed
  - Release pressure at the desired speed
- 4 PULSATION MODES
  - 1<sup>st</sup> Press: Wave - Speed will vary gradually from maximum to minimum
  - 2<sup>nd</sup> Press: Pulse - Speed will go directly to minimum and then straight back to maximum
  - 3<sup>rd</sup> Press: Returns to maximum speed
- 5 ON/OFF LIGHT
  - 1<sup>st</sup> Press: Light ON - WHITE
  - 2<sup>nd</sup> Press: Light OFF
  - Turn OFF and ON within 3 seconds the light will change to:
  - SLOW - RAINBOW CYCLE;
  - FAST - RAINBOW CYCLE;
  - TURQUOISE;
  - BLUE;
  - MAGENTA;
  - RED;
  - ORANGE;
  - YELLOW;
  - GREEN;
  - return to SLOW RAINBOW CYCLE.

**DRYING CYCLE OPTIONS**

**STANDARD DRYING CYCLE**

An automatic drying cycle will start 20 minutes after the blower is turned off.

**STANDARD DRYING CYCLE WITH WATER DETECTORS**

They activate a drying cycle 20 minutes after the bathtub is emptied and thus even when the blower was not used.

**24H PROGRAMMABLE DRYING CYCLE**

The system must be stopped prior to activation or deactivation.

**Activation:** Determine at which time you wish the purge to activate.

At that precise time, press and hold the second button on the keypad for 5 seconds. The purge cycle will now start at the programmed time every 24 hrs. In the event of a power failure the program will be automatically deactivated.

**Deactivation:** press and hold the second button on the keypad for 5 seconds.

